

# Heat Tube/ Illumination Lamp

## Heat Tube/Illumination Lamp Chart

MODEL	ELEMENT PART # 120V	ELEMENT PART # 208V	ELEMENT PART # 240V	ILLUM. LAMP PT. # 120V	ILLUM. LAMP PT. # 240V
EZFW-18	110649	110772	110892	N/A	N/A
EZFW-24	110650	110773	110893	N/A	N/A
EZFW-30	110653	110776	110896	N/A	N/A
EZFW-36	110655	110778	110898	N/A	N/A
EZFW-42	110921	110922	110923	N/A	N/A
EZFW-48	110657	110780	110900	N/A	N/A
EZFW-54		(1)EZT-30, (1)EZT-24		N/A	N/A
EZFW-60	110653	110776	110896	N/A	N/A
EZFW-66		(1)EZT-36, (1)EZT-30		N/A	N/A
EZFW-72	110655	110778	110898	N/A	N/A
EZFW-78		(1)EZT-48, (1)EZT-30		N/A	N/A
EZFW-84		(1)EZT-48, (1)EZT-36		N/A	N/A
EZFW-90	110653	110776	110896	N/A	N/A
EZFW-96	110657	110780	110900	N/A	N/A
EZFW-102		(2)EZT-36, (1)EZT-30		N/A	N/A
EZFW-108	110655	110778	110898	N/A	N/A
EZFW-114		(1)EZT-48, (1)EZT-35, (1)EZT-30		N/A	N/A
EZFW-120	110653	110776	110896	N/A	N/A
EZFW-126		(2)EZT-48, (1)EZT-30		N/A	N/A
EZFW-132		(2)EZT-35, (2)EZT-30		N/A	N/A
EZFW-138		(3)EZT-35, (1)EZT-30		N/A	N/A
EZFW-144	110657	110780	110900	N/A	N/A
EZLFW-18	110649	110772	110892	000370	000378
EZLFW-24	110650	110773	110893	000370	000378
EZLFW-30	110653	110776	110896	000370	000378
EZLFW-36	110655	110778	110898	000370	000378
EZLFW-42	110921	110922	110923	000370	000378
EZLFW-48	110657	110780	110900	000370	000378
EZLFW-54		(1)EZT-30, (1)EZT-24		000370	000378
EZLFW-60	110653	110776	110896	000370	000378
EZLFW-66		(1)EZT-35, (1)EZT-30		000370	000378
EZLFW-72	110655	110778	110898	000370	000378
EZLFW-78		(1)EZT-48, (1)EZT-30		000370	000378
EZLFW-84		(1)EZT-48, (1)EZT-36		000370	000378
EZLFW-90	110653	110776	110896	000370	000378
EZLFW-96	110657	110780	110900	000370	000378
EZLFW-102		(2)EZT-36, (1)EZT-30		000370	000378
EZLFW-108	110655	110778	110898	000370	000378
EZLFW-114		(1)EZT-48, (1)EZT-36, (1)EZT-30		000370	000378
EZLFW-120	110653	110776	110896	000370	000378
EZLFW-126		(2)EZT-48, (1)EZT-30		000370	000378
EZLFW-132		(2)EZT-36, (2)EZT-30		000370	000378






# PD-4 Pop-Down Toaster

► \* **Important:** Starting with s/n WPD0013330 all 120V models will be equipped with a 20 Amp plug. The following parts should be used for these models only:

- **Heater Card** -120V - #51128
- **Timer w/Potentiometer** -120V - #51306
- **Cordset, NEMA 5-20P** -120V - #41143


All other parts are as listed on the following page.






**CALL FOR PRICING ON A NEW UNIT!**

# RB-33VS Conveyor BunToaster





<b>PART NO.</b>	<b>DESCRIPTION</b>
21219	Cordset - NEMA 6-20P 208/240V
51216	Cordset- NEMA 5-30P 120V
12542	Reflector Tray
112105	Chute Toast Tray
12405	Chute, Rear Delivery Only
12668	Leg, 1" Adjustable (4 qty.)
12543	Trim, Front
12523	Savory Logo
12219	Trim, Left Hand Front
12328	Trim, Right Hand Front
14702	Infinite Control Switch, 208V
21874	Infinite Control Switch, 120V
12355	Infinite Control Switch, 240V
21213	On/Off Switch
12919	Infinite Control Knob
13302	Conveyor Speed Control 208/240V
12464	Conveyor Speed Control 120V
12447	Conveyor Speed Control Knob
12500	Wire Harness Kit (Wires Only)
21858	Terminal Block
18035	Resistor
18036	Resistor Clamp
21358	Jumper

<b>PART NO.</b>	<b>DESCRIPTION</b>
12412	Drive Chain, 55 Links
12508	Tension Adjusting Bracket (2 qty.)
21319	32T Sprocket
30494	8T Drive Sprocket (for 208/240V Units)
12467	6T Drive Sprocket (for 120V Units)
21849	Motor Bracket
21212	Gearmotor Assembly w/Fan 208/240V
21211	Gearmotor Assembly w/Fan 120V
12463	120V Element 1100W (2 qty.)
12126	208V Element 1200W (2 qty.)
12149	240V Heater Assembly
12494	208V Heater Assembly
12149	240V Heater Assembly
21282	Bearings (4 qty.)
12381	Bearing Retainer (4 qty.)
12552	Conveyor Chain, Coated
12483	Conveyor Chain Link, Coated (45 qty.)
12549	Front Shaft Assembly
12548	Rear Shaft Assembly
12548	Rear Shaft Assembly
12534	Bushing, Rear (2 qty.)
12533	Bushing, Front (2 qty.)
30042	Savory Lubricant