


# Performer II Series Convection Oven




**Performer II Convection Oven**

ITEM NO.	PART NO.	DESCRIPTION
1	282285	Motor Guard
1A	228129	Motor Only - 1/4 HP
1B	252757	Motor Pad Assembly
2	228130	Blower Wheel/Fan
2A	225249	Bolts for Motor Mount - 1/4" - 20"
2B	225053-2	Hex Nut - 1/4" 20" x 7/16"
3	261543	Blower Cover - (Black)
3A	261543-1	Blower Cover - (Porcelain)
4	261590-1	Spacer - Inside Fan Guard
4A	261590-2	Spacer - Outside Fan Guard
5	225076	Washer
6	282092	Flue Assembly
6A	261545-1	Flue Spout Assembly
7	282067-2	Door Gaskets - Top and Bottom
7A	282068	Door Gaskets - Sides
8	282431-1	Control Bracket - R/H - 36" & 72" Units Only (Side)
8A	282431-2	Control Bracket - L/H - 36" & 72" Units Only (Side)
9	227157	Buzzer - 36" & 72" Units Only
10	228000	Terminal Block - 36" & 72" Units Only
11	227160-2	Solenoid Valve w/Bracket
12	227168	Spark Module
13	227175	Flame Switch
14	228265	Timer - 36" & 72" Units Only
15	224230-1	Knob (Gray)-Timer & TST-36" & 72" Units Only
16	227155	Thermostat - Electric (KX Type)
16A	225222	Capillary Bulb Holder
16B	224233	TST Knob - 48" & 60" Units Only
16C	224232	Insert for Knob - 48" & 60" Units Only
16D	224279	Overlay for Knob - 48" x 60" Units Only
16E	224237	Bezel - 48" & 60" Units Only
17	228264-1	3-Way Switch-On/Off/Cool Down (White)
18	228007-3	Indicator Light - (Red)
19	282065-1	Control Panel Bracket-36" & 72" Units Only-Decal

ITEM NO.	PART NO.	DESCRIPTION
20	229125	Control Face Plate Decal - 48" & 60" Units Only (Gray)
20A	229127	Control Face Plate Decal - 36" & 72" Units Only (Gray)
21	282045-1	Control Cover Assembly - R/H - 36" & 72" Units Only
21A	282045-2	Control Cover Assembly - L/H - 36" & 72" Units Only
22	229129	Wiring Diagram - 48" & 60" Units Only
22A	229129-1	Wiring Diagram - 36" & 72" Units Only
23	227185	Pilot Burner Assembly w/Leads - NAT
24	282075	Door Switch Bracket - L/H - 36" & 72" Units Only
24A	282075-1	Door Switch Bracket - R/H - 36" & 72" Units Only
25	227034	Microswitch/Doorswitch
26	282441-2	Front Baffle
27	228210-1	Electrical Power Cord
28	226061	Oven Rack - 25-7/8" x 20-9/16"
29	226050	Oven Rack Support (L/H or R/H)
30	282442	Bottom Orifice Bracket - 48" & 60" Only
30A	223000-1	Orifice Elbow 90 w/o Orifice/Trailer Pilot
30B	223073	Elbow 90 - 3/8" x 3/8" NPT
30C	223076	Elbow 90 (1/8")
30D	223076	Oven Burner
31	223242-40	Oven Burner Orifice - NAT
31A	223242-53	Oven Burner Orifice - LP
31B	227049-18	Oven Pilot Orifice - NAT
31C	227049-10	Oven Pilot Orifice - LP
32	282457	Oven Aeration Pan
33	252773	Nipple/Tapped - 3/8" x 2"
34	223079	Half Union/Brass 3.8" x 1/4" Brass
35	225072	Screw - 10 - 1/2"
36	225009	Insulating Washer-3/4" OD x 1/4" ID x 1/8"
37	225010	Hex Nut, 8-32
38	225094	Fastener - 6 - 32" x 1-1/2"
39	225013	Hex Nut - 6 - 32



# Performer II Restaurant Series Range



**Performer II Restaurant Series**

► NOTE: \* Have to order separately - knob, insert and overlay to make up complete thermostat dial. (GS thermostat only)


ITEM NO.	PART NO.	DESCRIPTION
1	Griddle Plate	Specify Model - Left or Right Side Drain
1A	282234	Pilot Tubing Assembly - 1 Per Burner - Griddle
1B	282211	Burner Assembly - Griddle
1C	223005-4	Air Shutter - Griddle Burner
1D	Griddle	Fire Box Side Rail Assembly- Specify Model No.
2	282227	Hot Top Plate Assembly - 12"
2A	282234	Pilot Tubing Assembly - Hot Top (1) Per Section
2B	282211	Burner Assembly - Hot Top
2C	282228	Hot top frame Assembly - 12"
2D	223005-4	Air Shutter - Hot Top Burner
3	282554	Open Top Burner Assembly - (Front)
4	282555	Open Top Burner Assembly - (Rear)
4A	222162	Open Burner Head Only
4B	222171	Venturi/Air Shutter - Front Burner - SS
4C	222172	Venturi/Air Shutter - Rear Burner -SS
4D	224005	Gasket/Burner Head - (Cast Iron Venturi Only)
4E	224005-1	Gasket/Burner Head - (SS - Venturi Only)
4F	223005	Air Shutter - (Cast Iron Venturi Only)
4G	225233	Bolts (Open Burner Head to Venturi)
4H	227053	Burner Valve - Open Top, Griddle & Hot Top - w/o Orifice
4I	224002	Burner Valve Knob - Open Top, Griddle & Hot Top Metal
5	282244	Open Burner Hanger Assembly
5A	282241	Open Burner Pilot Tubing Assembly
6	222157	Top Grate - Open Burner
7	282024-1	Landing Ledge - 24" - Top
	282024-2	Landing Ledge - 36" - Top
	282024-3	Landing Ledge - 60" - Top
	282024-4	Landing Ledge - 48" - Top
	282024-5	Landing Ledge - 72" - Top
8	Valve Cover	Specify Model & s/n
9	Manifold Assembly	Specify Model & s/n

ITEM NO.	PART NO.	DESCRIPTION
10	227005	Oven Manual Shut Off Valve
11	282080-01	Oven Bottom with Flame Spreader - 20" Oven
	282080-02	Oven Bottom with Flame Spreader - 26" Oven
12	282059	Oven Burner with Air Shutter Assembly
12A	223242-42	Oven Burner Orifice - NAT - 20" Oven
	223242-53	Oven Burner Orifice - LP - 20" Oven
	223242-34	Oven Burner Orifice - NAT - 26" Oven
	223242-51	Oven Burner Orifice - LP - 26" Oven
12B	227184	Oven Pilot Burner - NAT (Mounted on L/S of Burner)
	227184-1	Oven Pilot Burner - LP (Mounted on L/S of Burner)
	227198	Oven Pilot Burner - NAT (Mounted on R/S of Burner)
	227198-1	Oven Pilot Burner - LP (Mounted on R/S of Burner)
12C	227049-18	Oven Pilot Orifice - NAT - 20" Oven
	227049-10	Oven Pilot Orifice - LP - 20" Oven
	227049-18	Oven Pilot Orifice - NAT - 26" Oven
	227049-10	Oven Pilot Orifice - LP - 26" Oven
12D	223242-46	Open Burner Orifice - NAT
	223242-55	Open Burner Orifice - LP
	223242-48	Hot Top Burner Orifice - NAT
	223242-56	Hot Top Burner Orifice - LP
	223242-51	Griddle Burner Orifice - NAT (Thermostat Control)
	223242-57	Griddle Burner Orifice - LP - (Thermostat Control)
	223242-44	Griddle Burner Orifice - NAT - (Manual Control)
	223242-54	Griddle Burner Orifice - LP - (Manual Control)
13	227071	Oven Safety Pilot Valve - Baso Type
13A	282534	Safety Pilot Bracket
13B	225065	Bolt for Bracket - 10 - 24 x 2-1/2"
13C	225066	Hex Nut for Bracket - 10 - 24"
13D	223280	Orifice Elbow - w/o Orifice - Oven - 1/4" x 3/8"
14	282441-1	Front Burner Compartment Baffle - 20" Oven
14A	282441-2	Front Burner Compartment Baffle - 26" Oven

(Illustration on page 614.)

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
15	227199	Pilot Valve Adjustment (Used Across the Board)	22	282135	Door Closure Mechanism Assembly - 20"
16	Control Panel	Specify Model & s/n		282115	Door Closure Mechanism Assembly - 26"
17	227181-1	Thermostat - Oven - GS Type	22A	282068	Oven Door Seal (Sides) - 20" & 26" Oven
17A	227181-2	Thermostat - Griddle - GS Type	22B	282067-1	Oven Door Seal (Top) - 20" Oven
17B	227054	Thermostat - Oven - "BJ Type" (2-Hole)	22C	282067-2	Oven Door Seal (Top) - 26" Oven
17C	227000	Thermostat - Griddle - "BJ Type" (2-Hole)	23	282022-1	Kick Plate - SS - 20" Oven
17D	225222	Capillary Bulb Holder - Oven TST		282022-2	Kick Plate - SS - 26" Oven
18*	224233	Thermostat Knob - Black		282478-1	Kick Plate - Black - 20" Oven
18A*	224232	Insert (Red) Between Thermostat Stem & Knob		282478-2	Kick Plate - Black - 26" Oven
18B*	224279	Overlay (Degrees) Oven Thermostat	23A	282043	Kick Plate Bracket Assembly
18C*	224280	Overlay (Degrees) Griddle Thermostat	23B	227183	Thermocouple
18D	224002	Burner Knob (Black) Plastic - Open Top - On/Off	24	282437	Grease Can - Griddle - 2" Wide
18E	224274-1	Knob (Red) On/Off - Oven - GS TST	24A	252114-0	Grease Can - Griddle - 4" Wide
18F	224274-3	Knob (Red) On/Off - Griddle - GS TST	25	282033-1	Drip Pan - Open Top - 12"
18G	224022	Dial - Oven - "BJ" Type TST		282033-2	Drip Pan - Open Top - 24"
18H	224000	Dial - Griddle - "BJ" Type TST		282033-3	Drip Pan - Open Top - 36"
18I	228111	Bezel - Oven TST	26	226060-1	Oven Rack - 20" Oven - 20-9/16" x 19-7/8"
18J	228112	Bezel - Griddle TST		226060-2	Oven Rack - 26" Oven - 20-9/16" x 26-3/8"
19	229000	U.S. Range Emblem - (Blue)	27	223283	6" Cone Leg
20	282130	Oven Door Assembly - SS - 20" Oven	27A	224073	Foot Insert
	282110	Oven Door Assembly - SS - 26" Oven	28	223277-1	Caster w/Brake
	282130-1	Oven Door Assembly - Black - 20" Oven	28A	223277-2	Caster w/o Brake
	282110-1	Oven Door Assembly - Black - 26" Oven	28B	225248	Bolt for Casters & Legs (4 Per Leg or Caster)
21	282131-1	Oven Door Liner - Porc - 20" Oven	28C	225076	Lockwashers - Caster & Legs (4 Per Leg or Caster)
	282111-1	Oven Door Liner - Porc - 26" Oven	29	282260-1	High Shelf Assembly - SS - 24" Range
	282134	Oven Door Front Panel - SS - 20" Oven		282260-2	High Shelf Assembly - SS - 36" Range
	282114	Oven Door Front Panel - SS - 26" Oven		282260-3	High Shelf Assembly - SS - 60" Range
	282477	Oven Door Front Panel - Black - 20" Oven		282260-4	High Shelf Assembly - SS- 48" Range
	282476	Oven Door Front Panel - Black - 26" Oven		282260-5	High Shelf Assembly - SS- 72" Range
21A	221187-14	Oven Door Handle - 20" Oven		282260-6	High Shelf Assembly - Black - 24" Range
	221187-15	Oven Door Handle - 26" oven		282260-7	High Shelf Assembly - Black - 36" Range
21B	224225	Door Handle Bracket, Plated		282260-8	High Shelf Assembly - Black - 60" Range
21C	224242	Door Handle Spacer		282260-9	High Shelf Assembly - Black - 48" Range
21D	225005	Door Handle Bolt 1/4 x 20 x 3/4		282260-10	High Shelf Assembly - Black - 72" Range

# IRCMA Series Cheese Melter



## Infrared Cheese Melter

ITEM NO.	PART NO.	DESCRIPTION	IRCMA						
			24	36	48	60	72	96	120
1	222105-1	Infrared Burner - 18 3/4" x 5"	1		2	1	3	4	5
	222106-1	Infrared Burner - 29 1/2" x 5"		1		1			
2	227097	90 Orifice Elbow	1	1	2	1	3	4	5
	227061-46	Orifice Elbow Assembly - NAT	1		2	1	3	4	5
	227061-55	Orifice Elbow Assembly - LP				(Optional)			
	227061-39	Orifice Elbow Assembly - NAT		1					
	227061-52	Orifice Elbow Assembly - LP				(Optional)			
	227059-46	Orifice Only - NT	1		2	1	3	4	5
	227059-55	Orifice Only - LP				(Optional)			
3	227041	Pilot Burner	1	1	2	1	3	4	5
	253361-1	Pilot Tubing Assembly - Complete	1	1	2	1	3	4	5
	253361-2	Pilot Tubing Assembly - Complete				1			
						(Optional)			

(Illustration on page 617.)

ITEM NO.	PART NO.	DESCRIPTION	24	36	48	IRCMA 60	72	96	120
	253360-1	Manifold Assembly - 24"	1						
	253360-2	Manifold Assembly - 36"		1					
	253360-3	Manifold Assembly - 48"			1				
	253360-4	Manifold Assembly - 60"				1			
	253360-5	Manifold Assembly - 72"					1		
	253360-6	Manifold Assembly - 96"						1	
	25330-7	Manifold Assembly - 120"							1
5	223019	90 Elbow - 3/4"	1	1	1	1	1	1	1
6	221130-8	Intake Pipe - 3/4" x 8"	1	1	1	1	1	1	1
7	253350-1	Valve Cover - 24"	1						
	253350-2	Valve Cover - 36"		1					
	253350-3	Valve Cover - 48"			1				
	253350-4	Valve Cover - 60"				1			
	253350-5	Valve Cover - 72"					1		
	253350-6	Valve Cover - 96"						1	
	253350-7	Valve Cover - 120"							1
8	227199	Pilot Valve - Adjustable	1	1	2	2	3	4	5
9	227005	Burner Valve	1	1	2	2	3	4	5
10	224015	Burner Valve Knob	1	1	2	2	3	4	5
11	226004	Wire Shelf - 13" x 21-1/2"	1						
	226010	Wire Shelf - 13" x 33-1/2"		1					
	226005	Wire Shelf - 13" x 45-1/2"			1				
	226011	Wire Shelf - 13" x 57-1/2"				1			
	226006	Wire Shelf - 13" x 69-1/2"					1		
	226007	Wire Shelf - 13" x 93-1/2"						1	
	226008	Wire Shelf - 13" x 117-1/2"							1
12	253002-51	Bracket for Range Mounting	1	1	1	1	1	1	1
12A	253370-1	Wall Mounting Bracket - 24"	1		2	2	3	3	4
	253370-2	Wall Mounting Bracket - 36"		1					
13	253340-1	Top Cover - 24"	1						
	253340-2	Top Cover - 36"		1					
	253340-3	Top Cover - 48"			1				
	253340-4	Top Cover - 60"				1			
	253340-5	Top Cover - 72"					1		
	253340-6	Top Cover - 96"						1	
	253340-7	Top Cover - 120"							1
	228052-13	Pressure Regulator - 3/4" NAT	1	1	1	1	1	1	1
	228052-14	Pressure Regulator - 3/4" LP							

(Optional)